



Multiview 3D video / Outline


* Camera geometry


- Pinhole camera model
- Projective geometry
- Projection matrix,
- Intrinsic/extrinsic camera parameters
- * Camera calibration



Adv. Topics MMedia Video / 5LSH0 / Mod 02 3D intro & multiview video









So, this hour we learn

Mapping between image and world coordinates

- Pinhole camera model
- Projective geometry
 - · Vanishing points and lines
- Projection matrix



Adv. Topics MMedia Video / 5LSH0 / Mod 02 3D intro & multiview video




How can we create something that captures the scenery?





TU/e PdW-SZ-EB / 2017 Fac. EE SPS-VCA


Adv. Topics MMedia Video / 5LSH0 / Mod 02 3D intro & multiview video





































































Homogeneous coordinates

- In projections on our image sensor, we do not know distances to objects
- So, we need to write scale-invariant coordinates (independent on distance)
 - · Use homogeneous coordinates
 - · By adding one more parameter

Converting to homogeneous coordinates

$$(x,y) \Rightarrow \begin{bmatrix} x \\ y \\ 1 \end{bmatrix}$$

homogeneous image coordinates



Adv. Topics MMedia Video / 5LSH0 /



35

33

Homogeneous coordinates

Invariant to scaling

$$k \begin{bmatrix} x \\ y \\ w \end{bmatrix} = \begin{bmatrix} kx \\ ky \\ kw \end{bmatrix} \Rightarrow \begin{bmatrix} \frac{kx}{kw} \\ \frac{ky}{kw} \end{bmatrix} = \begin{bmatrix} \frac{x}{w} \\ \frac{y}{w} \end{bmatrix}$$

Homogeneous Coordinates

Cartesian Coordinates

Point in Cartesian is ray in Homogeneous



Adv. Topics MMedia Video / 5LSH0 /



Homogeneous coordinates

Converting to homogeneous coordinates

$$(x,y) \Rightarrow \begin{bmatrix} x \\ y \\ 1 \end{bmatrix}$$

homogeneous image

homogeneous 3D scene coordinates

Converting from homogeneous coordinates

$$\begin{bmatrix} x \\ y \\ w \end{bmatrix} \Rightarrow (x/w, y/w) \qquad \begin{bmatrix} x \\ y \\ z \\ w \end{bmatrix} \Rightarrow (x/w, y/w, z/w)$$





36

Multiview 3D video / Outline

* Camera geometry


- Pinhole camera model
- Projective geometry
- Projection matrix,
- Intrinsic/extrinsic camera parameters
- * Camera calibration


Adv. Topics MMedia Video / 5LSH0 /





Camera Projection Matrix


TU/e Pdw-Sz-EB / 2017 Adv. Topics MMedia Video / 5LSH0 / Mod 02 3D intro & multiview video VCA

































































Camera Matrix

We can finally map a 3D point to the image!

$$\begin{bmatrix} u \\ v \\ 1 \end{bmatrix} = \begin{bmatrix} \alpha & s & u_0 \\ 0 & \beta & v_0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} r_{11} & r_{12} & r_{13} & t_x \\ r_{21} & r_{22} & r_{23} & t_y \\ r_{31} & r_{32} & r_{33} & t_z \end{bmatrix} \begin{bmatrix} x \\ y \\ z \\ 1 \end{bmatrix}$$

Adv. Topics MMedia Video / 5LSH0 / Mod 02 3D intro & multiview video



63

Unfortunately, not yet.

We need to find these parameters for each camera, first

$$w \begin{bmatrix} u \\ v \\ 1 \end{bmatrix} = \begin{bmatrix} \alpha & s & u_0 \\ 0 & \beta & v_0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} r_{11} & r_{12} & r_{13} & t_x \\ r_{21} & r_{22} & r_{23} & t_y \\ r_{31} & r_{32} & r_{33} & t_z \end{bmatrix} \begin{bmatrix} x \\ y \\ z \\ 1 \end{bmatrix}$$



62

Multiview 3D video / Outline


- * Camera geometry
 - Pinhole camera model
 - Projective geometry
 - Projection matrix,
 - Intrinsic/extrinsic camera parameters
- * Camera calibration

Adv. Topics MMedia Video / 5LSH0 /



Projective camera / Summary – (2)

* Combining the camera matrix (intrinsic parameters) and the rotation/translation matrix (extrinsic parameters) we obtain the camera calibration matrix C.



* Projection matrix 3x4 has 11 degrees of freedom (scaling invariance).

TU/e PdW-SZ-EB / 2017 Fac. EE SPS-VCA

Adv. Topics MMedia Video / 5LSH0 / Mod 02 3D intro & multiview video



Camera calibration

- * Goal: estimating coefficients of the camera calibration matrix.
 - Once the camera calibration matrix parameters are known, the camera is "calibrated".



- * Simple calibration algorithm
 - It is assumed that the world coordinates of 3D points are known with their corresponding 2D pixel coordinates.
 - Points are usually arranged in a special pattern for easy calibration.



Adv. Topics MMedia Video / 5LSH0 /



Linear method for estimating matrix C – (2)

- st Use world point coordinates p_w and their corresponding pixel coordinates p_{ip} in the image to determine C.

$$\begin{array}{l} - \ \, \text{Each correspondence generates two equations} \\ x_{ip} = \frac{x_w p_{11} + y_w p_{12} + z_w p_{13} + p_{14}}{x_w p_{31} + y_w p_{32} + z_w p_{33} + p_{34}} \\ y_{ip} = \frac{x_w p_{11} + y_w p_{12} + z_w p_{13} + p_{14}}{x_w p_{31} + y_w p_{32} + w z_w p_{33} + p_{34}} \\ \text{hich can be written as} \end{array}$$

which can be written as

$$x_{ip}(x_w p_{31} + y_w p_{32} + z_w p_{33} + p_{34}) = x_w p_{11} + y_w p_{12} + z_w p_{13} + p_{14}$$

$$y_{ip}(x_w p_{31} + y_w p_{32} + w z_w p_{33} + p_{34}) = x_w p_{11} + y_w p_{12} + z_w p_{13} + p_{14}$$



Adv. Topics MMedia Video / 5LSH0 / Mod 02 3D intro & multiview video



Linear method for estimating matrix C - (1)

* World-point coordinates and image-pixel positions are linked with the camera calibration matrix

$$\begin{pmatrix} \lambda x_{ip} \\ \lambda y_{ip} \\ \lambda \end{pmatrix} = \begin{pmatrix} p_{11} & p_{12} & p_{13} & p_{14} \\ p_{21} & p_{22} & p_{23} & p_{24} \\ p_{31} & p_{32} & p_{33} & p_{34} \end{pmatrix} \begin{pmatrix} x_w \\ y_w \\ z_w \\ 1 \end{pmatrix}$$

- *P is the 3x4 projection matrix, can be written as C=K[R|t]
- * Algorithm consists of two steps:
 - 1. Compute matrix C with a set of known 3D positions and their respective positions in the image.
 - 2. Extrinsic and intrinsic parameters are estimated from C.





Linear method for estimating matrix C – (3)

* Stack equations into one equation system:

- * The equation has 12 unknown parameters: at least 6 correspondence points are required.
- * Typically, more points are used.
 - Equation system gets over-constrained.
 - Equation is then solved using a least squares minimization.



Adv. Topics MMedia Video / 5LSH0 /



